

# LUMINA



## Installation manual

Dimensions:  
120x180 cm  
150x180 cm  
150x200 cm



Handedness:  
Left




# Leave space for better assembly



# Tools




# 1. Base frame




	A/C (mm)	B/D (mm)
120x180 cm	1178	1770
150x180 cm	1478	1770
150x200 cm	1478	1970




## 2. Walls



### 3. Multiclip closing system







# 4. Fixing walls A1 & B1




# 5. Fixing wall A2 & B2

No. 1 (5x80)







## 6. Fixing corner post






# 7. Fixing walls C1&C2



# 8. Fixing ceilings



## 9. Wiring inside walls




# 10. Interior

120x180 cm


150x180 cm

150x200 cm




- 1. Block for fixing backrests
- 2. Backrests
- 3. Upper bench grid
- 4. Upper bench frame
- 5. Lower bench grid
- 6. Lower bench frame
- 7. Platform
- 8. Additional support for model 120x180 cm


# 10.1 Assembly of platform



## Fixing platform




# 10.2 Upper bench frame & blocks for backrest



1. Frontside of the bench frame & platform have to be same level with paneling as shown

## 10.3 Cariitti optic fibre for upper bench (Optional)




- A. Projector
- B. Power cable
- C. Fibre

1. Push down power cable from the ceiling
2. Connect power cable with projector
3. Push fiber in gap between upper bench frontboards
4. Connect fibre with projector





# 10.4 Lower bench frame fixing




- 1. Frontside of the bench frame have to be same level with paneling as shown
- 2. Push LED-strip to ceiling for connection


# 10.5 Additional support fixing 120x180 cm



# 11. Backrest LED-strips



# 11.1 Fixing backrests



## 12. Interior II


120x180 cm

150x180 cm


150x200 cm

AUROOM


Our Saunas Your Wellness




# 13. Fixing heater guard



# 14. Glass wall & door frames




# 15. Fixing glass wall & door frames








# 15.1 Fixing glass wall






# 15.2 Multiclips for frames

RS-1




 No. 3 (4x50)

# 15.3 Door hinges and glass




1. Fix door hinges to frame with screws
2. Place door glass between hinges
3. Assembly handle
3. Read hinge manual for regulation


# 16. Upper frame




# 17. Fixing upper frame




# 18. Front frame



# 19. Fixing front frame




# 20. Floor frames



No. 1 (5x80)


FL-1

FL-2






# 20.1 Floor grids



# 21. Wiring on ceilings



- 1. Control unit cable
- 2. Heater cable
- 3. Backrest LED-strips
- 4. 230 V for carriti optic fiber (optional)
- 5. Lower bench LED-strip
- 6. Junction boxes (J1,J2,J3,J4)
- 7. Transformer
- 8. Power unit
- 9. Lamp cable (optional)
- 10. Speakers (optional)

**!** Always use certified electrician